



OWNER'S MANUAL
Model Number

700694-2



BERCO
Winter soft cab 40" for compact tractor

* ASSEMBLY
* OPERATION

* REPAIR PARTS
* MAINTENANCE

CAUTION:
READ & FOLLOW ALL SAFETY RULES & INSTRUCTIONS BEFORE
OPERATING YOUR EQUIPMENT



LIMITED WARRANTY

Conditions and Products Covered:

BERCOMAC guarantees any part of the product or accessory manufactured by BERCOMAC and found in the reasonable judgment of BERCOMAC to be defective in material and or workmanship will be repaired or replaced by an authorized dealer without charge up to our maximum labor rates and pre-established times. For replacement parts only standard ground freight services are covered. This warranty extends to the original retail purchaser only and is not transferable to any subsequent purchasers. This warranty applies to the products bought and used in North America.

Warranty Period

(from date of the original retail purchase)

- Residential use: 1 year
- Semi-commercial, professional or rental use: 90 days

Exceptions Noted Below; the following items are guaranteed by the original manufacturer and have their own warranty, conditions and limited time:

- Tire Chains: 90 days
- Engines: Will vary as per the manufacturer

Please refer to the engine manufacturer's warranty statement included with the unit. BERCOMAC is not authorized to handle warranty adjustments on engines.

Items and Conditions NOT Covered:

This warranty does not cover the following:

- Pick-up or delivery charges or in-home services fees.
- Any damage or deterioration of the unit, parts and or finish of these due to normal use, wear and tear, or exposure.
- Cost of regular use or maintenance service or parts, such as gas, oil, lubricants, tune-up parts, and adjustments.
- Any part or accessory which has been altered, modified, misused, neglected, accidentally damaged or not properly installed, maintained, stored or repaired not in accordance with the instructions in the owner's manual.
- Repair due to normal wear and or any wear items such as shear pins, bolts, belts, etc.
- Expedited freight fee services for replacement parts.
- Shear bolts and shear pins are to be considered as a preventive measure not as an assured protection, any damages resulting from the lack of shear bolts breakage are not covered.
- Damages due to product being installed on a vehicle other than stipulated in owner's manual.

NOTE: All warranty work must be performed by an authorized dealer using original (manufacturer) replacement parts.

NOTE: Bercomac reserves the right to change or improve the design of any part or accessory without assuming any obligation to modify any product previously manufactured.

Instructions for Obtaining Warranty Services:

Contact dealer where equipment was purchased or any other BERCO service dealer to arrange service at their dealership. Requests for warranty claims must be carried out through the same distribution network used to purchase the product. Don't forget to bring your proof of purchase (sales receipt) to the BERCOMAC dealer.

Owner's Responsibilities:

BERCOMAC's defective equipment or part must be returned to an authorized dealer within the warranty period for repairs. In the event that defective merchandise must be returned to manufacturer for repairs, freight fees are prepaid and a written authorization from BERCOMAC must be obtained by dealer prior to the shipment. This warranty extends only to equipment operated under normal conditions. To validate a warranty claim, it is the user's responsibility to maintain and service the unit as specified in the owner's manual or to have the unit serviced at their dealer at their expense.

General Conditions:

The sole liability of BERCOMAC with respect to this warranty shall be strictly and exclusively repair and replacement as mentioned herein. BERCOMAC shall not have any liability for any other costs, loss or damage, including but not limited to, any incidental or consequential loss or damage.

Taking advantage of the warranty does not in any way extend the length or renewal of the warranty.

In particular, without being limited to, BERCOMAC shall have no liability or responsibility for:

- Travel time, overtime, after hours time or other extraordinary repair charges or relating to repairs and or replacements outside of normal business hours.
- Rental of like or similar replacement equipment during the period of any, repair or replacement work.
- Any communicating or travel charges.
- Loss or damage to person or property other than that covered by the terms of this warranty.
- Any claims for lost revenue, lost profit or any similar costs as a result of damage or repair.
- Attorney's fees.

BERCOMAC's responsibility in respect to claims is limited to making the required repairs or replacement without charge up to our maximum labor rates and pre-established times and no claim of breach of warranty shall be cause for cancellation or rescission of the contract of sale of any product or accessory. In no event recovery of any kind be greater than the amount of the purchase price of the product sold.

This warranty gives you specific legal rights. You may also have other rights, which vary from state to state.

TABLE OF CONTENTS

	PAGE
INTRODUCTION	2
SAFETY PRECAUTIONS	3
SAFETY DECALS	5
ASSEMBLY	
Step 1: Vehicle preparation.....	6
Step 2: Rear brackets installation	7
Step 3: Front brackets intallation.....	9
Step 4: Assembling the frame - Roof top.....	12
Step 5: Assembling the frame.....	13
Step 6: Canvas Installation	13
OPERATION	15
MAINTENANCE	16
TORQUE SPECIFICATION TABLE	17
PARTS BREAKDOWN AND LISTS	18

INTRODUCTION

TO THE PURCHASER

This new accessory was carefully designed to give years of dependable service. This manual has been provided to assist in the safe operation and servicing of your attachment.

NOTE: All photographs and illustrations in the manual may not necessarily depict the actual models or attachment, but are intended for reference only and are based on the latest product information available at the time of publication.

Familiarize yourself fully with the safety recommendations and operating procedures before putting the machine to use. Carefully read, understand and follow these recommendations and insist that they be followed by those who will use this attachment.



THIS SAFETY ALERT SYMBOL IDENTIFIES AN IMPORTANT SAFETY MESSAGE IN THIS MANUAL THAT HELPS YOU AND OTHERS AVOID PERSONAL INJURY OR EVEN DEATH. DANGER, WARNING, AND CAUTION ARE SIGNAL WORDS USED TO IDENTIFY THE LEVEL OF HAZARD. HOWEVER, REGARDLESS OF THE HAZARD, BE EXTREMELY CAREFUL.

DANGER: Signals an extreme hazard that will cause serious injury or death if recommended precautions are not followed.

WARNING: Signals a hazard that may cause serious injury or death if the recommended precautions are not followed.

CAUTION: Signals a hazard that may cause minor or moderate injury if the recommended precautions are not followed.

Record your attachment serial number and purchase date in the section reserved below (there is no serial number on the subframe). Your dealer requires this information to give you prompt, efficient service when ordering replacement parts. Use only genuine parts when replacements are required.

If warranty repairs are required please present this registration booklet and original sales invoice to your selling dealer for warranty service.

**This manual should be kept for future reference.
Please check if you have received all the parts for your kit with the list of the bag and the list of the box.**

SERIAL NUMBER : (IF APPLICABLE)	
MODEL NUMBER:	
PURCHASE DATE :	



SAFETY PRECAUTIONS



Careful operation is your best insurance against an accident. Read this section carefully before operating the vehicle and accessory. This accessory is capable of amputating hands and feet and throwing objects. Failure to observe the following safety instructions could result in serious injury. All operators, no matter how experienced they may be, should read this and other manuals related to the vehicle and accessory before operating. It is the owner's legal obligation to instruct all operators in safe operation of the accessory.

GLOSSARY:

In this manual, right and left sides are determined by sitting on the seat of the vehicle facing forward.

In this manual, "accessories" means attachments (snowblower, rotary broom, blade etc.) that you install on the vehicle (lawn tractors, A.T.V. s etc).

TRAINING:



This symbol, "Safety Alert Symbol", is used throughout this manual and on the accessory's safety labels to warn of the possibility of serious injury. Please take special care in reading and understanding the safety precautions before operating the vehicle and accessory.

1. Read this owner's manual carefully. Be thoroughly familiar with the controls and proper use of the vehicle and accessory. Know how to stop the unit and disengage the controls quickly.
2. Never allow children to operate the vehicle nor the accessory. Never allow adults to operate the vehicle nor the accessory without proper instructions.
3. No one should operate the vehicle nor the accessory while intoxicated or while taking medication that impairs the senses or reactions.
4. Keep the area of operation clear of all people, particularly small children and pets.
5. Never start or operate the accessories except from the operator's station on the power unit except if this is impossible.

PREPARATION:

1. Thoroughly inspect the area where the accessory is to be used and remove door mats, all foreign objects and the like.
2. For motorized accessories, disengage all clutches and shift into neutral before starting engine.
3. Do not operate the accessory without wearing adequate winter outer garments. Avoid loose fitting clothing that can get caught in moving parts. Wear footwear that will improve footing on slippery surfaces.

4. Handle fuel with care, it is highly flammable.
 - a) Use approved fuel container.
 - b) Never add fuel to a running engine or hot engine.
 - c) Fill fuel tank outdoors with extreme care. Never fill fuel tank indoors.
 - d) Never fill containers inside a vehicle, or on a truck or a trailer bed with a plastic liner. Always place containers on the ground, away from your vehicle, before filling.
 - e) When practical, remove gas-powered equipment from the truck or trailer and refuel it on the ground. If this is not possible, then refuel such equipment on a trailer with a portable container, rather than from a gasoline dispenser nozzle.
 - f) Keep the nozzle in contact with the rim of the fuel tank or container opening at all times, until refueling is complete. Do not use a nozzle lock-open device.
 - g) Replace fuel cap securely and wipe up spilled fuel.
 - h) If fuel is spilled on clothing, change clothing immediately.
5. Never attempt to make any adjustments while the engine (motor) is running (except when specifically recommended by manufacturer).
6. Let the vehicle and accessory adjust to outdoor temperatures before using.
7. Never use an accessory without proper guards, plates, or other safety protective devices in place
8. Always make sure to wear the appropriate safety equipment required (glasses, muffs, mask...) for each type of product. See operation section.
9. Always make sure of having safe traction on the vehicle by using the recommended accessories (chains, A.T.V. tracks, counterweights...). See operation section.
10. Always make sure all components are correctly installed. (driveline securely attached and locked at both ends, belts properly installed...)
11. If applicable, always handle the winch cable with thick leather gloves.
12. **Never modify the accessory or any part without the written consent from the manufacturer.**



SAFETY PRECAUTIONS



OPERATION:

1. Do not put hands or feet near, under or inside rotating parts.
2. Exercise extreme caution when operating on or crossing gravel drives, walks or roads. Stay alert for hidden hazards or traffic. Do not carry passengers.
3. After striking a foreign object, stop the engine (motor), disconnect the wire from the spark plug(s) and keep wire away to prevent accidental starting. Thoroughly inspect the accessory for any damage and repair damage before restarting and using the accessory.
4. If the unit should start to vibrate abnormally, stop the engine (motor) and check immediately for the cause. Vibration is generally a warning of trouble.
5. Take all possible precautions when leaving the vehicle unattended. Disengage the power take-off, lower the attachment, place the transmission into neutral, set the parking brake, stop the engine and remove the ignition key.
6. Do not run the engine indoors, except when starting the engine and for transporting in or out of the building. Do not operate or let motor run in a storage area without ventilation because gas contains carbon monoxide which is odorless, colorless and can cause death.
7. Never use the accessories across the face of slopes, go from top to bottom. Exercise extreme caution when using equipment on slopes. Do not attempt to clear a steep slope.
8. Never tolerate bystanders in the working zone. Never use an accessory in the direction of bystanders, it might throw gravel or debris that can hurt people or damage property.
9. Never operate the accessory at high transport speeds on slippery surfaces. Use care when backing up.
10. Do not carry passengers.
11. Disengage power to the accessory when it is transported or not in use.
12. Never operate the accessory without good visibility or light.
13. Keep the accessory away from heat sources or flames.
14. If applicable, never handle the winch cable or hook while in tension.

MAINTENANCE AND STORAGE

1. When cleaning, repairing or inspecting the vehicle and accessory: stop the engine, set brake, remove ignition key, and wait that all moving parts have stopped. For gasoline engine, disconnect wire from the spark plug(s) and keep wire away to prevent accidental starting.
2. Check all the bolts and components at frequent intervals to make sure that they are properly tightened.
3. Never store a motorized accessory with fuel in the fuel tank inside a building where ignition sources are present such as hot water and space heaters, clothes dryers, and the like. Allow the engine to cool before storing in any enclosure.
4. Always refer to the owner's manual when you store the accessory and vehicle for a prolonged or an unspecified length of time.
5. Maintain or replace safety and instruction labels, as necessary.
6. For winter accessories, (if applicable), let the engine run for a few minutes after clearing snow in order to prevent the rotary parts from freezing.
7. Inspect the vehicle's and accessory's air filter (if applicable) every day. Clean it or replace it as necessary. Change the oil more often when working in dusty conditions. See the vehicle's and accessory's owner's manual.

TRANSPORT

1. Review Transport Safety instructions in vehicle manual before moving.
2. Check with local authorities regarding transport on public roads. Obey all applicable laws and regulations.
3. Make sure all lights and reflectors that are required by the local highway and transport authorities (example : SMV (Slow Moving Vehicle)) are in place, are clean, and can be seen clearly by all overtaking and oncoming traffic.
4. Never have the equipment in operation during transport.
5. Always travel at a safe speed.



SAFETY DECALS



REPLACE IF DECALS ARE DAMAGED
SEE PARTS BREAKDOWN FOR DECAL LOCATION

Symbol	Description
<p data-bbox="261 445 456 478">Decal #107160</p> 	<p data-bbox="597 485 1321 518">Carbon monoxide (CO) can cause brain damage or death.</p> <p data-bbox="597 541 1430 600">Engine exhaust contains odorless and colorless carbon monoxide gas.</p> <p data-bbox="597 627 1403 686">Signs of carbon monoxide poisoning include nausea, headache, dizziness, drowsiness, and lack of consciousness.</p> <p data-bbox="597 714 1442 747">Get fresh air if anyone shows signs of carbon monoxide poisoning.</p> <p data-bbox="597 772 1373 831">Read all Owner's Manual safety precautions regarding carbon monoxide poisoning.</p>

ASSEMBLY

INSTALLATION INFORMATION:

IMPORTANT: There is a potential risk of the paint wearing off from the hood or the decal coming off due to cab rubbing against it. To lessen this potential damage, a soft cloth may be inserted between the cab and hood. Wiping down the hood after each use will also help.

NOTE: (for the winter cab) The windows are made of top quality cold resistant, clear flexible plastic. Under extreme cold conditions, all plastics become fragile. Never hit or scrape windows, this could damage them. These damages, under these conditions, are not covered by the manufacturer's warranty.

TOOLS REQUIRED FOR EASY INSTALLATION

2 Locking pliers
1 wrench 10mm
1 wrench 3/8"
2 wrench 7/16"
2 wrench 9/16"
1 Steel saw
1 Deburring tool

Drill bit 13/32"
Electric Drill
1 Philips screwdriver
1 Pair of cutters

Read and understand the instructions before starting installation.

Please sort out and identify all the hardware before starting installation. Lists for the hardware bag and for the box are supplied in each.

STEP 1

CAB BRACKETS INSTALLATION:

Install the brackets for your vehicle following the instructions.



CAUTION



Make sure the canvas for the cab is not too tight :

- The dimensions specified at step 1 must not be exceeded. This will stretch the canvas and prematurely wear out the seams, zippers,...



WARNING



Since this a universal kit, it is the owner's / user's responsibility to:



- To make sure the brackets do not interfere in any way with the braking or engaging pedals or any other controls on the vehicle. Any interference with the brackets could hinder the vehicle's controls and cause an accident.
- The same goes with any interference with the security mechanisms (such as lights, reflectors,...): never disable any of the security mechanisms.
- To make sure when installation is finished, the brackets are able to support the weight of the cab and any snow accumulation (even if it is specified to never leave any snow accumulate on the cab). This implies either modifying/reinforcing the brackets supplied in this kit.
- To make sure there is never any snow accumulation on the cab.
- To respect all the security instructions supplied in the owner's manual for the cab.
- To make sure that neither the brackets nor the cab come into interference with any moving parts.
- To respect at all times the security instructions in the tractor's user manual.
- To make sure that neither the brackets nor the cab interfere with the normal displacement of the user on the tractor, when getting on or when getting off the tractor. This is to avoid falling off the tractor or causing any injuries.
- To make sure that the brackets are not located at any location that could injury to a person who moves around the parked or moving vehicle.

ASSEMBLY

APPROXIMATE POSITION OF THE BRACKETS :

With the help of these measurements (see below) locate the approximate position of the brackets for the cab.

This will help locate the brackets.



ASSEMBLY

STEP 2

REAR BRACKET INSTALLATION:


The rear brackets are installed on the rear protection bar of the vehicle. (ROPS)

OPTION A : INSTALLATION ON PROTECTION BAR

Place the rear support bracket (item 1) against the vehicle's protection bar (item A) put 2 pieces of rubber foam between the support and the vehicle's protection bar.


Position the brackets (item 2) on the other side of the protection bar. Place a piece of rubber foam (item 3) under the brackets.

Secure in place with 4 bolts (M10 X 80 or M10 X 100) (item 4) according to the thickness of the protection bar (item A), flat washers 7/16" (item 5) and nuts (item 6). Use holes B1, B2, B3, B4 according to the thickness of the protection bar and make sure the bracket matches.



Install the rear support (item 1) on the rear support bracket installed in the preceding step) with a bolt M10 X 30 (item 2), 2 flat washers 7/16" (item 3) and nuts (item 4) as shown.

Finally install the coupling nuts (item 5) with the bolt M6 x 1.00 x 25 (item 6) on the rear support as shown. Put some high strength red thread locker to make sure the assembly does not loosen. To tighten in place, use a pair of locking pliers to hold the coupling nuts in place while tightening the bolt.



NOTE: Make sure the coupling nuts are perpendicular to the ground. If this is not the case, it is possible to bend the rear support, but it is recommended to wait until the cab has been installed in the right position to do this adjustment.



ASSEMBLY

OPTION B : OTHER WAYS TO INSTALL TEH BRACKETS

On certain vehicles, Type A installation is not possible because of the dimensions of the protection bar or of its design. In these cases there are other ways to get around the problem:

- If the protection bar has bolts, use them to secure the rear support.
- Use only the rear support by bending it and putting it on vehicle's bolt.
- Installing elsewhere other than on the protection bar.
- Make a new rear bracket that will adapt in a better way on the protection bar.
-

NOTE: Make sure the coupling nuts are perpendicular to the ground. If this is not the case, it is possible to bend the rear support, but it is recommended to wait until the cab has been installed in the right position for doing this adjustment.



WARNING



If you are using the bolts on the protection bar, these safety warnings also apply in addition to the safety warnings on the first page of the assembly instructions:

- If longer bolts are necessary, use the same size and the same grade as the original bolts,
- Make sure to always follow the torque specification table
- Always use some thread locker if nylon insert lock nuts are not used. If there are nylon lock nuts, replace them with new lock nuts.
- If a bolt goes through an oblong hole, it is mandatory to use a flat washer in order to make sure that the bolt is well tightened.

ASSEMBLY

STEP 3 FRONT BRACKET INSTALLION:


OPTION A: INSTALLATION ON THE SIDE OF TRACTOR'S FOOTRESTS

POSITIONNING THE SUPPORTS

Press the front side support against the footrest with the slotted holes toward the top as shown in the picture. Hold in place with a pair of locking pliers

Temporarily install the coupling nuts (item 2) to validate the position of front side support and its length. Then, validate installation by putting the cab on the brackets that are temporarily installed.

If the cab is too long or too short (see step 1) move the coupling nut forward or backward. If the cab is too wide or not wide enough use the extension (item 3) then put the coupling nut on the extension.



FINISHING THE INSTALLATION


Drill two 13/32" holes in the tractor's footrest. Using the side support as a template to drill. Use two holes as far as possible from each other. Also, make sure that you don't have any interference with any components under the footrest. Finally cut the support if needed.

Install the support on the tractor's footrest using 2 bolts M10 X 25 (item 4) washer 7/16 (item 5) and nut M10 (item 6) as illustrated

Install the coupling nut (item 2), a bolt M6 x 1.00 x 25 (item 7) and a lock washer (item 8) with two 5/16" washer on each side of the support (item 9) using red thread locker. To tighten in place, use a pair of locking pliers to hold the coupling nuts in place while tightening the bolt

NOTE:

If necessary, install the extension (item 3) to put the coupling nuts (item 2). To install : install 2 bolts M6 X 25 (item 10) with 2 flat washers 5/16" and nuts M6 as shown.



CAUTION



Make sure the canvas for the cab is not too tight :

- The dimensions specified at step 1 must not be exceeded. This will stretch the canvas and prematurely wear out the seams, zippers,...

NOTE: Make sure the coupling nuts are perpendicular to the ground. If this is not the case, it is possible to bend the support, but it is recommended to wait until the cab has been installed in the right position to do this adjustment.

ASSEMBLY

OPTION B: ON THE TRACTOR'S FOOTRESTS

To identify the parts, the principal front support is a lot thicker than the secondary front support.

PRINCIPAL FRONT SUPPORT:


Start by locating the holes or bolts on the tractor's foot rest.

Then place the small hole (Item A) on the principal front support (item 1) over these holes in order to determine the best possible location.

The best possible location is determined by using the approximate location determined in A to make sure that the location will be over a hole in the principal support.

Once this is determined, install the coupling nut (item 2), a bolt M6 x 1.00 x 25 (item 3) and a lock washer (item 4) with two 5/16" washer on each side of the support (not illustrated) and hold in place with a pair of locking pliers. Do this on both sides.

Then, validate installation by putting the cab on the brackets that are temporarily installed.



NOTE:

If necessary, it is possible to use the extension (item 5) to put on the coupling nuts (item 2). If necessary, install 2 bolts M6 X 25 (item 6) with 2 flat washers 5/16 and nuts 1/4 as shown.



NOTE: Make sure the coupling nuts are perpendicular to the ground. If this is not the case, it is possible to bend the support, but it is recommended to wait until the cab has been installed in the right position to do this adjustment.



CAUTION



Make sure the canvas for the cab is not too tight :

- The dimensions specified at step 1 must not be exceeded. This will stretch the canvas and prematurely wear out the seams, zippers,...

ASSEMBLY

SECONDARY FRONT SUPPORT :


Chose another hole on the footrest in order to install the secondary crosspiece.

Place the small hole (Item A) on the secondary front support (item 1) over these holes in order to determine the best possible location.

The best possible location is determined by:

- It must be possible to link the principal crosspiece to the secondary crosspiece with a bolt (item 2), therefore a location which allows to install this bolt.
- The angle between the principle and secondary front supports must be as close as possible to a 90 degree angle.
- The connection point between the principal and secondary front supports must be as close as possible to the coupling nuts.

Once this has been determined, install the bolt M6 X 25 (item 2) with the nuts and 2 flat washers 5/16 as shown.



FINISHING THE INSTALLATION

Now that everything is correctly located, drill the small holes (hole A and B) on the principal and secondary front supports of the appropriate dimension in order to install on the vehicle according to the required bolts on the latter.

The bolts that allow you to install the supports on the vehicle are not included with this kit. Since every vehicle is different, the latter must be purchased locally.

When installing the cross pieces on the vehicle be careful of:

- Make sure everything is well tightened between the supports and the parts on the vehicle.
- Do not use the location of the bolts that hold assembled tractor parts unless you are sure there will be no security issues.

Finally, cut the surplus from the supports making sure to round out the corners and make sure to not cut through an oblong hole but between two holes.

Install the coupling nut with thread locker like at the back. Tighten all the bolts according to the torque specification table.



ASSEMBLY



WARNING



It's the owner/user responsibility to make sure the front supports do not interfere in anyway with the brake & clutch pedals or any other tractor controls at any time. Any interference from the supports may block the controls and cause an accident. Do not disable any safety device on the vehicle.


STEP 4 FRAME ASSEMBLY—ROOF:

Assemble the top portion of the frame by attaching the link tubes (item 1) to the side tubes (item 2) and in the middle, the reinforcement tubes (item 3) (angled portion facing upwards).

Secure loosely with the #10 x 1" machine screws (item 4) (screw heads on top) with the nylon insert lock nuts (item 5).

Place the assembly on a level surface to ensure that the structure is level. Moderately tighten all the screws.

NOTE: Wrap machine screws with resistant adhesive tape to prevent premature wear of the canvas



Assemble the roof


INSTALLATION OF ROOF REINFORCEMENT:

Position roof reinforcement (item 1) onto frame's assembly (item 2) and connect together with 18 nylon tie wraps.

Note: Be sure that the nylon tie wraps pass around the side tubes.

Note: Only tighten nylon tie wraps once the roof's reinforcement is centered onto the frame's assembly insuring the head's of the tie wraps are underneath the roof.

Cut off any exceeding tie wraps.



ASSEMBLY


STEP 5 FRAME ASSEMBLY:

Install front posts (item 1) and rear posts (item 2) onto front support rods (item 3) and rear (item 4) as shown.

*Figure is for illustrative purpose only, the supports (installed at step 1) depends on vehicle model, make and options.

Place frame's roof of the winter cab onto the posts.

Note: If vehicle is equipped with a front loader and a hydraulic command system, remove the adjustment part located at the front right side of the winter cab. Pass the hydraulic control system through the opening that was created.



STEP 6 CANVAS INSTALLATION:

Open zippers on the sides of the cab. Install the canvas onto the winter cab's frame by positioning the front part first.

Attach all velcro straps into their supports to secure the winter cab into place.



CAUTION




To avoid premature damage to cab windows, unfold cab at minimum 10°C - 50°F

ASSEMBLY

Many pieces of material have been fabricated for different types of tractors as per those with a front loader.

Use whichever fits the best depending of your vehicle's options.



WARNING



- Never block the air vents.
- As this is an universal cab, there is many tractor models, makes and options that can affect the quantity of carbon monoxide (CO) in the cab.
- Carbon monoxide (CO) can cause brain damage or death.
- Exhaust fumes should never enter the cab, they contain carbon monoxide (CO) which is odorless, colorless and deadly.
- It is the installer's/owner's/user's responsibility to make sure no carbon monoxide (CO) is entering the cab at any time. To do that; make sure the tractor's exhaust system is in good condition and not oriented towards the cab.
- The installer/owner/user must buy and install a carbon monoxide (CO) detector to be placed inside the cab that suit the use of the cab.
 - For a commercial application (8hour/day max) the detection level must be lower than 35ppm
 - For a residential application (1hour/day max) the detection level must be lower than 200ppm
 - The detector must be working at a temperature range that suits the temperature range where the cab is being used. The same goes for the humidity level.
 - Use and install the CO detector following it's manufacturer's instructions.
 - The CO detector must be keep functional and in good condition at all time.
- If any question contact Bercomac's support.



WARNING



- Diesel exhaust fumes contains gases and particles
- Diesel exhaust is classified : "carcinogenic to humans" by WorldHealthOrganization
- It is the installer's/owner's/user's responsibility to make sure that exhaust fumes should never enter the cab

OPERATION

OPERATION

- Keep the windows clear and clean in order to keep a good visibility at all times. Wash the windows with a mild soap such as dishwashing soap and a soft cloth.
- During the winter use a soft brush to sweep off the snow. DO NOT HIT the windows with the brush or your hands to remove the snow. This will crack the vinyl.
- Keep air vents clear and clean at all times.



WARNING



- Never block the air vents.
- As this is an universal cab, there is many tractor models, makes and options that can affect the quantity of carbon monoxide (CO) in the cab.
- Carbon monoxide (CO) can cause brain damage or death.
- Exhaust fumes should never enter the cab, they contain carbon monoxide (CO) which is odorless, colorless and deadly.
- It is the installer's/owner's/user's responsibility to make sure no carbon monoxide (CO) is entering the cab at any time. To do that; make sure the tractor's exhaust system is in good condition and not oriented towards the cab.
- The installer/owner/user must buy and install a carbon monoxide (CO) detector to be placed inside the cab that suit the use of the cab.
 - For a commercial application (8hour/day max) the detection level must be lower than 35ppm
 - For a residential application (1hour/day max) the detection level must be lower than 200ppm
 - The detector must be working at a temperature range that suits the temperature range where the cab is being used. The same goes for the humidity level.
 - Use and install the CO detector following it's manufacturer's instructions.
 - The CO detector must be keep functional and in good condition at all time.
- If any question contact Bercomac's support.



WARNING



- Diesel exhaust fumes contains gases and particles
- Diesel exhaust is classified : "carcinogenic to humans" by WorldHealthOrganization
- It is the installer's/owner's/user's responsibility to make sure that : exhaust fumes should never enter the cab



WARNING



WEARING EAR MUFFS IS REQUIRED WHILE OPERATING THE TRACTOR WITH THE CAB



WARNING



TO AVOID PERSONAL INJURY CAUSED BY CAB COLLAPSING: Remove any accumulation on the top of the cab



WARNING



KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TRACTOR WINTER CAB

MAINTENANCE

MAINTENANCE

Check mounting bolts on the frame at frequent intervals for proper tightness to be sure equipment is in safe working condition.

END OF SEASON STORAGE

- a) Thoroughly wash and dry the canvas.
- b) Inspect for any tears or unstitched seams. Repair if necessary.
- c) Carefully remove the canvas from the frame.
- d) Roll up instead of folding the canvas for summer storage.
- e) Store the canvas in a well ventilated place, away from all weather elements and out of reach of rodents.
- f) The frame must be cleaned and dried before storing in a dry enclosed place.
- g) Inspect and replace all defective parts before using again.

TORQUE SPECIFICATION TABLE

GENERAL TORQUE SPECIFICATION TABLE USE THE FOLLOWING TORQUES WHEN SPECIAL TORQUES ARE NOT GIVEN


NOTE: These values apply to fasteners as received from supplier, dry or when lubricated with normal oil. They do not apply if special graphited or moly disulphide greases or other extreme pressure lubricants are used. This applies to both UNF and UNC threads.

* Thick nuts must be used with grade 8 bolts

SEE Grade No.		2				5				8 *			
BOLT HEAD IDENTIFICATION MARKS AS PER GRADE NOTE MANUFACTURING MARKS WILL VARY		TORQUE				TORQUE				TORQUE			
BOLT SIZE		FOOT POUNDS		NEWTON-METERS		FOOT POUNDS		NEWTON-METERS		FOOT POUNDS		NEWTON-METERS	
Inches	Millimetre	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.
1/4"	6.35	5	6	6.8	8.13	9	11	12.2	14.9	12	15	16.3	30.3
5/16"	7.94	10	12	13.6	16.3	17	20.5	23.1	27.8	24	29	32.5	39.3
3/8"	9.53	20	23	27.1	31.2	35	42	47.5	57	45	54	61	73.2
7/16"	11.11	30	35	40.7	47.4	54	64	73.2	86.8	70	84	94.9	113.9
1/2"	12.7	45	52	61	70.5	80	96	108.5	130.2	110	132	149.2	179
9/16"	14.29	65	75	88.1	101.6	110	132	149.2	179	160	192	217	260.4
5/8"	15.88	95	105	128.7	142.3	150	180	203.4	244.1	220	264	298.3	358
3/4"	19.05	150	185	203.3	250.7	270	324	366.1	439.3	380	456	515.3	618.3
7/8"	22.23	160	200	216.8	271	400	480	542.4	650.9	600	720	813.6	976.3
1"	25.4	250	300	338.8	406.5	580	696	786.5	943.8	900	1080	1220.4	1464.5

METRIC BOLT TORQUE SPECIFICATIONS							
		COARSE THREAD			FINE THREAD		
Size Screw	Grade No.	Pitch (mm)	Foot Pounds	Newton-Meters	Pitch (mm)	Foot Pounds	Newton-Meters
M6	4T	1.00	3.6 - 5.8	4.9 - 7.9	-	-	-
	7T		5.8 - 9.4	7.9 - 12.7		-	-
	8T		7.2 - 10	9.8 - 13.6		-	-
M8	4T	1.25	7.2 - 14	9.8 - 19	1.00	12 - 17	16.3 - 23
	7T		17 - 22	23 - 29.8		19 - 27	25.7 - 36.6
	8T		20 - 26	27.1 - 35.2		22 - 31	29.8 - 42
M10	4T	1.50	20 - 25	27.1 - 33.9	1.25	20 - 29	27.1 - 39.3
	7T		34 - 40	46.1 - 54.2		35 - 47	47.4 - 63.7
	8T		38 - 46	51.5 - 62.3		40 - 52	54.2 - 70.5
M12	4T	1.75	28 - 34	37.9 - 46.1	1.25	31 - 41	42 - 55.6
	7T		51 - 59	69.1 - 79.9		56 - 68	75.9 - 92.1
	8T		57 - 66	77.2 - 89.4		62 - 75	84 - 101.6
M14	4T	2.00	49 - 56	66.4 - 75.9	1.50	52 - 64	70.5 - 86.7
	7T		81 - 93	109.8 - 126		90 - 106	122 - 143.6
	8T		96 - 109	130.1 - 147.7		107 - 124	145 - 168
M16	4T	2.00	67 - 77	90.8 - 104.3	1.50	69 - 83	93.5 - 112.5
	7T		116 - 130	157.2 - 176.2		120 - 138	162.6 - 187
	8T		129 - 145	174.8 - 196.5		140 - 158	189.7 - 214.1
M18	4T	2.00	88 - 100	119.2 - 136	1.50	100 - 117	136 - 158.5
	7T		150 - 168	203.3 - 227.6		177 - 199	239.8 - 269.6
	8T		175 - 194	237.1 - 262.9		202 - 231	273.7 - 313
M20	4T	2.50	108 - 130	146.3 - 176.2	1.50	132 - 150	178.9 - 203.3
	7T		186 - 205	252 - 277.8		206 - 242	279.1 - 327.9
	8T		213 - 249	288.6 - 337.4		246 - 289	333.3 - 391.6

NOMENCLATURE ET LISTE DES PIÈCES / PARTS BREAKDOWN & PART LIST
 Cabine d'hiver souple pour tracteur compact #700694-2
 Winter soft cab for compact tractor #700694-2



NOMENCLATURE ET LISTE DES PIÈCES / PARTS BREAKDOWN & PART LIST
Cabine d'hiver souple pour tracteur compact #700694-2
Winter soft cab for compact tractor #700694-2

REF.	ENGLISH DESCRIPTION	DESCRIPTION FRANÇAISE	QTY.	PART#
1	40" Winter Canvas	Toile d'hiver 40"	1	107011
2	Adjustment part	Pièce d'ajustement	1	107010
3	Adjustment part	Pièce d'ajustement	1	107008
4	Adjustment part	Pièce d'ajustement	1	107009
5	Rear Post	Poteau arrière	2	106659
6	Front Post	Poteau avant	2	106660
7	Reinforcement tube	Tube de renforcement	2	107013
8	Link tube	Tube de liaison	2	104353
9	Side tube	Tube de côté	2	106663
10	Roof stiffener	Renfort de toit	1	107719
11	Front support extension	Extension de support avant	2	107380
12	Bracket	Fixation	4	107382
13	Rubber foam	Pellicule de caoutchouc	8	107383
14	Rear support	Support arrière	2	107384
15	Hex. bolt M6 x 1.00 x 25 GR8.8	Boulon hex. M6 x 1.00 x 25 GR8.8	10	O/L (310.8.8P_M6X1.00X25)
16	Hex. bolt M10 x 1.50 x 25 GR8.8	Boulon hex. M10 x 1.50 x 25 GR8.8	4	O/L (310.8.8P_M10X1.50X25)
17	Hex. bolt M10 x 1.50 x 30 GR8.8	Boulon hex. M10 x 1.50 x 30 GR8.8	2	O/L (310.8.8P_M10X1.50X30)
18	Hex. bolt M10 x 1.50 x 80 GR8.8	Boulon hex. M10 x 1.50 x 80 GR8.8	8	O/L (310.8.8P_M10X1.50X80)
19	Hex. bolt M10 x 1.50 x 100 GR8.8	Boulon hex. M10 x 1.50 x 100 GR8.8	8	O/L (310.8.8P_M10X1.50X100)
20	Nylon Insert lock Nut M6 x 1.00	Écrou à garniture de nylon M6 x 1.00	6	O/L (352.P_M6X1.00)
21	Nylon Insert lock Nut M10 x 1.50 GR8.8	Écrou à garniture de nylon M10 x 1.50 GR8.8	14	O/L (352.P_M10X1.50)
22	Coupling nut M6 x 1.00 x 40mm	Écrou d'accouplement M6 x 1.00 x 40mm	4	O/L (354.P_M6X1.00X40)
23	Flat washer 5/16" hole	Rondelle plate 5/16" trou	16	O/L (360.P_5-16T)
24	Flat washer 7/16" hole	Rondelle plate 7/16" trou	16	O/L (360.P_7-16T)
25	Lock washer 1/4"	Rondelle de blocage 1/4"	4	O/L (362.P_1-4)
26	Principal front support	Support avant principal	2	107378
27	Secondary front support	Support avant secondaire	2	107379
28	Rear support bracket	Fixation de support arrière	2	107381
29	Front side support	Support avant latéral	2	107440
30	Machine screw Pan head no.10 x 24 x 1"	Vis mécanique tête pan no.10 x 24 x 1"	8	O/L (395NC.P_#10x24x1)
31	Nylon Insert lock Nut #10x24 n.c.	Écrou à garniture de nylon #10x24 n.c.	8	O/L (335NC.P_#10X24)
32	Tie wrap 11"	Attache de nylon 11"	18	O/L (426-11)

O/L = Obtain Locally



***WHEN PERFORMANCE
& DEPENDABILITY
ARE NON NEGOTIABLE!***

**Bercomac Limitée
92, Fortin North, Adstock, Quebec, Canada, G0N 1S0**

WWW.BERCOMAC.COM

PRINTED IN CANADA

(ORIGINAL NOTICE)