



PARTS BREAKDOWN ELECTRIC AIR COMPRESSOR

MODEL:AC3220B



BEPOWEREQUIPMENT


.COM



PARTS BREAKDOWN ELECTRIC AIR COMPRESSOR

MODEL:AC3220B

TANK ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
2	Metal Handle	1	42.004.500
11	Foam Handle Grip	1	
47	Screw	2	
12	Rubber Foot Pad	2	42.004.505
13	Flat Washer	2	
14	Bolt	2	
15	Tank Drain Valve	1	42.004.012
16	Axel Bolt	2	42.004.506
17	Wheel	2	
18	Nut	2	
19	Pump Discharge Pipe	1	42.004.521
20	Tank Check Valve	1	42.004.508
21	Unloader Copper Fitting	1	
22	Unloader Pipe	1	



PARTS BREAKDOWN ELECTRIC AIR COMPRESSOR


MODEL:AC3220B

PRESSURE SWITCH ASSEMBLY



REF #	DESCRIPTION	QTY	BE PART #
3	Pressure Gauge	1	42.003.006
4	Safety Valve	1	42.010.150
5	Pressure Switch	1	42.004.519
7	Regulator	1	42.004.504
8	Pressure Gauge	1	42.003.005
9	T-Pipe Fitting	1	42.000.018
10	Quick Coupler	2	42.000.046

PUMP ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
23	Hex Nut	4	42.004.510
24	Spring Washer	4	
25	Bolt	4	
26	Pump Assembly (Pulley Included)	1	
27	Oil Plug	1	42.004.523
Not Shown	Air Filter Assembly	1	42.004.524



PARTS BREAKDOWN ELECTRIC AIR COMPRESSOR


MODEL:AC3220B

MOTOR ASSEMBLY



REF #	DESCRIPTION	QTY	BE PART #
27	Motor Bolt	4	42.004.511
28	Washer	4	
29	Hex Nut	4	
48	Cable Gland	1	
32	Motor	1	42.004.512
30	Allen Head Bolt	1	
31	Motor Pulley	1	

BELT GUARD ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
33	Belt	1	42.004.513
34-43	Belt Guard Assembly	1	42.004.514
40-42	Belt Guard Support Bracket Assembly	1	42.004.515



PARTS BREAKDOWN ELECTRIC AIR COMPRESSOR

MODEL:AC3220B

COMPLETE ASSEMBLY (REFERENCE ONLY)



BE

POWER EQUIPMENT

If you need technical assistance call:

1-866-850-6662

(8:00am - 4:30pm PST, Mon - Fri)