



# PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE1200I

---



---

**BEPOWEREQUIPMENT**


**.COM**



# PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE1200I

## CYLINDER HEAD AND COVER



REF #	DESCRIPTION	QTY	BE PART #
5	Cylinder Head Gasket	1	85.571.538
6	Spark Plug	1	85.571.522

## CRANKCASE




REF #	DESCRIPTION	QTY	BE PART #
2	Intake Studs	2	85.571.568
3	Exhaust Studs	2	
7	Low Oil Sensor	1	85.571.620
9	Engine Oil Plug Subassembly	1	85.571.539



# PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE1200I

## RECOIL STARTER/AIR FILTER



REF NO.	DESCRIPTION	QTY	PART NO.
3	Shroud	1	85.571.627
7	Air Cleaner Element	1	
8	Air Cleaner Case Cover	1	
5	Recoil Assembly	1	85.571.540
7	Air Cleaner Element	1	85.571.541

## CARBURETOR ASSEMBLY




REF NO.	DESCRIPTION	QTY	PART NO.
1	Carburetor Gasket	1	85.571.542
2	Carburetor Insulator Plate	1	
3	Carburetor Insulator Gasket	1	
4	Carburetor Assembly	1	
5	Air Cleaner Gasket	1	
9	Cap	1	
10	Fuel Strainer	1	
11	Clamp	1	
12	Fuel Tube	1	
10	Fuel Strainer	1	85.571.575



# PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE1200I

## FUEL TANK



REF NO.	DESCRIPTION	QTY	PART NO.
1	Fuel Cap	1	85.571.543
2	Fuel Strainer	1	
10	Fuel Pump Assembly	1	85.571.545
11	Nut	1	
12	Clamp	1	
13	Fuel Tube	1	
14	Clamp	1	

## IGNITION COIL




REF NO.	DESCRIPTION	QTY	PART NO.
4	Ignition Coil	1	85.571.546



# PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE1200I

## SHELL



REF NO.	DESCRIPTION	QTY	PART NO.
1	Left Cover Board	1	85.571.530
3	Right (recoil side) Cover Board	1	85.571.531
5	Left Shell	1	85.571.532
6	Right (recoil side) Shell	1	85.571.533

## INVERTER




REF NO.	DESCRIPTION	QTY	PART NO.
1	Inverter Assembly	1	85.571.549
4	Engine Cushion Right	2	85.571.659
6	Engine Cushion Left	2	



# PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE1200I

## CONTROL PANEL




REF NO.	DESCRIPTION	QTY	PART NO.
1	Control Panel Assembly	1	85.571.547
2	Crosshead Bolts	4	
3	Panel Seat	1	
4	Hexagon Step Bolts	4	
6	Screw	3	85.571.548
7	Knob	1	
8	Switch Assembly	1	
9	Cover Plate	1	
10	Steel Ball	1	
11	Stopper Adjusting Spring	1	
12	Choke Handle Subassembly	1	
13	Fuel Valve Assembly	1	85.571.589
14	Bolt	1	
23	Red Parallel Socket	1	
24	Black Parallel Socket	1	85.571.590
25	Duplex Socket, 120v 20amp, Household	1	85.571.592
27	DC Socket	1	85.571.652
28	USB Socket	1	85.571.653



# PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE1200I

## MUFFLER SUBASSEMBLY



REF NO.	DESCRIPTION	QTY	PART NO.
7	Exhaust Outlet Gasket	1	85.571.635
8	Muffler Assembly	1	85.571.636
9	Spark Arrestor	1	85.571.637

## ROTOR/STATOR



REF NO.	DESCRIPTION	QTY	PART NO.
2	Stator	1	85.571.655
3	Rotor	1	
7	Bolt	1	
9	Nut	1	



# PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE1200I

## ALLIGATOR CLIPS ACCESSORY



REF #	DESCRIPTION	QTY	BE PART #
1	12v Alligator Clip Set	1	85.571.000



# BE

**POWER EQUIPMENT**

---

If you need technical assistance call:

**1-866-850-6662**

(8:00am - 4:30pm PST, Mon - Fri)