# **Specifications**

# Simple Design for Years of Dependable Service Life!

#### Chain:

400 hook-and-eye, all-steel link.

#### Flites:

447: 2 in. x 2 in. x 1/4 in. (51 mm x 51 mm x 6.35 mm) angle for 18 in. (457 mm) wide gutter

467: 4 in. (102 mm) high on outer edge for 18 in. (457 mm) wide gutter

### Flite Spacing:

12 in., 18 in. or 24 in. (305 mm, 457mm, 610 mm).

#### **Gutter Width:**

15 to 20 in. (381 to 508 mm) with 1/2 in. (13 mm) increments.

#### **Motor:**

2 hp., 3 hp., 5 hp., or 7-1/2 hp. available in single or three phase

#### **Drive Unit:**

Heavy-duty planetary speed reducer drive unit; belt and roller chain drive.

### Capacity:

41 cubic feet @ 36 FPM with 18 in. (457mm) flite spacing. Through trapdoor, 25 cubic feet/min.

### **Printed Warranty**

Patz equipment is guaranteed for a period of one year from date of sale or installation to be mechanically free of defects in material and workmanship under normal use and service.

Patz chain is backed by a 15-year (5-year full) extended written warranty. Compare the Patz chain's warranty with any other hook-and-eye chain warranty. You will see why Patz chain is your best investment. For your protection, insist on a printed warranty that details all of the items covered and exactly how compensation will be made.

<u>Note:</u> New Patz contact points must be installed at the same time as new Patz chain in order to qualify for warranty.



**CAUTION:** Never operate Patz equipment without all shields and guards in place. Safety is no accident. Before operating any piece of equipment, be sure to read and understand the operators manual. The manual should be kept with the machine at all times.

Additionally, make sure all safety shields and devices are functioning properly and are securely in place.



For some photos in this brochure, guards were removed for photographic purposes only to allow viewing of the equipment features. Before operating equipment, all guards must be in place. Because Patz continually improves and updates products, Patz reserves the right to change the construction of machines or attachments or any part thereof without incurring any obligation to make like changes on Patz machines, or attachments previously delivered. Specifications and prices subject to change without notice.



▲ Conveniently convey material into





▲ Metal shavings drop into this **grate-covered trough** where a Patz Material Mover conveys them to a storage bin.



**Since 1948** 

## **Proven Performance You Can Count On!**

**Patz Corporation** 

917 Business 141, POB 7 • Pound, Wisconsin 54161-0007 Ph: (920) 897-2251 • Fax: (920) 897-2142 www.patzcorp.com • info@patzcorp.com







