

HO-G4920-H100-09R

REPLACEMENT BOWL - H100 (POST 2008)

HO-G4920-H50-09R

REPLACEMENT BOWL - H50 (POST 2008)

HO-G4920-H200

REPLACEMENT BOWL - H200

HO-G1820-LW50

REPLACEMENT BOWL - LW50



HO-G4950-H100

H100 (All model years)

HO-G4950-H50

H50 (All model years)

**REPLACEMENT BOWL
& FLOAT COVER KIT**



*Post 2008 style shown above

HO-G4924-H100

FLOAT COVER - H100 (POST '93) INSULATED

HO-G4924-H50

FLOAT COVER - H50 (POST '93) INSULATED

HO-G4924-H100-09

FLOAT COVER - H100 (POST 2008) INSULATED

HO-G4924-H50-09

FLOAT COVER - H50 (POST 2008) INSULATED

HO-G4924-H200

FLOAT COVER - H200 (POST 2008) INSULATED

HO-G4958

FLEXIBLE SUPPLY HOSE
(POST '93)

HO-G4958-H200

FLEXIBLE SUPPLY HOSE
(H200 MODELS)



HO-P4822

(#10 GEAR CLAMP, HF10)
HOSE CLAMP



HO-G4952

CONTROL BOX PRE-WIRED
(H, HL MODELS ONLY)



H0502

THERMOSTAT



HLW-27

FUSE HOLDER



H0514

HOLD DOWN BRACKET +
HDW. (POST '93)



H0519

HOSE BRACKET HLW-93



H0523

H0523 BRASS ELBOW
(HLW-94)



H0524

H0524 BRASS FITTING &
NUT



H0544

ROUND PILOT LIGHT (KIT)
(POST '92)



HO-P4300

VALVE ASSEMBLY (KERICK)
C/W LINK ARM FOR FLOAT

HO-P4836

4" PLASTIC BALL FLOAT

HO-P4305HF (H200 MODEL)




HO-P4814-H100

ELEMENT (500 WATTS) - H100 (POST '93), 19" X 11"

HO-P4814-H50

ELEMENT (320 WATTS) - H50 (POST '93), 16" X 7"



H200 Model uses one of each of the above.