



Husky Farm Equipment Limited

7440 Wellington Rd. 17, R. R. # 2, Alma, On N0B 1A0
Phone 519-846-5329 Fax 519-846-9378 Toll Free 1-800-349-1122
husky@huskyfarm.ca www.huskyfarm.ca



REAR MOUNTED INJECTOR



- 4 Tooth with spring teeth and spring assemblies, Optional extra teeth up to 7
- Teeth are clamped on with U bolted assembly for ease of sliding and adjustment
- 10 foot tool bar on smaller spreaders with 21.5L x 16.1 tires, 12 foot tool bar on spreaders with 28L x 26
- 12" sweeps standard, 2" chisels optional
- Parallel link bar lift assembly with hardened wear bushings at all wear joints, phasing cylinders for even lift
- 4 hole to 7 hole canister with outlets all on one level
- 6" line into the canister , optional 8" inlet
- 3" hose lines to the Injector teeth
- Top spread of liquid with a few moments change over (no wrenches required)
- Large gauge wheels are mounted on tubing that is U bolted to the main tool bar by U bolts
- Gross Weight 2000 pounds for the Rear injector 4 tooth



- Options For Your Husky Injector
- 8" Discharge
 - Hydraulic drive
 - Disc covers to put manure on the ground and cover the soil over them
 - Disc covers for the side of the rear injector to cover in the soil
 - Aerways to pull or mount behind spreader for No Till ground
 - Drop spouts to put manure between corn rows
 - Boom to spread manure even at 18" above ground
 - Bourgault, Yetter or Koniskilde injector mounted on Husky tool bar
 - 3 point hitch available for any Husky Spreader



All Figures Are Approximate, Limited Warranty (3Months For Custom Operators), No Warranty On Sand Bedding.
For Full Details and Exact Figures, Please Confirm With Husky. 1-800-349-1122