Feed Management PRECISELY

EZ 2500 V Standard Offering



Provides durability, quality, and simplicity

- Provides basic features for most applications
- Hold Key to "freeze" the displayed weight when moving the equipment
- Remote display port
- Standard offering with every mixer
- Slimline profile fits nearly anywhere


EZ 3410



Programmable Mix Batching and Unloading

- Three program methods: Per Cow Basis, Percent Basis, and Total Ingredient Basis
- Preset Weight allows accurate management of loading and unloading.
- 200 ingredient memory capacity, alphanumeric keypad
- First Ingredient Resizing automatically adjust remaining ingredients
- Ingredient accumulation data is recorded internally, allowing for CSV data file download to PC
- Internal "alarm light and horn" alerts operator of approaching target weights









Added functions to improve Loading and Unloading Efficiency

- Large 1.7" (43 mm) white backlit COG is even easier to read than EZ 2500 V
- Preset Weight function provides improved accuracy and management of loading and unloading
- R Internal "alarm light and horn" alert operator of approaching target preset weights
- Rotation Counter/ Timer aids in controlling mix time

TMR 3610



Feed Management Indicator

- Program rations at your PC or from the front panel of your indicator
- Compatible with TMR Tracker[®] Feed
 Management Software
- Internal "alarm light and horn" alerts operator of approaching target weights
- Make "pen call weights" and "head count" changes at the indicator
- Multi-language help messages
- Keeps up-to-date feed changes or reuse data

Helm Welding Limited Call for flyer: 519-529-7627

LUCK

Tel: 519-529-7000 www.lucknowproducts.com Fax: 519-529-3260 www.digi-star.com ©2017 Digi-Star

We reserve the right to modify designs or implement product improvement, without any obligations with respect to goods purchased.

Feed Management



Basic Wireless Kit 15-1200-00

Installed in the loader, the Cab Control displays the same weight information as the scale.

- Cab Control displays the same weight information as the scale
- Increases load accuracy and efficiency
- Operator control of Tare, Zero, Net, or Gross weights
- Range up to 1000 ft. (depending on location)

Remote Display Options

RD 2500 V 14-0047-00



- Large 1.7" LCD display with alarm light
- Bright LCD backlight for dark or inclement conditions
- Impact resistant window
- Slimline profile

RD 4000 15-1201-00



LUCK NOW

- Large 4" LED ultra bright display
- Viewable from 200 feet
- Lighted load progression bar graph

Optional Accessories*

Remote Transmitter 12-8946-10



Set Tare or Zero and select Net or Gross weights from Loader Cab up to 100 ft away

 Advance the ingredient or pen when using batching indicators

Alarm Horn 12-8969-10



Provides a loud audible alarm for precise loading and unloading

Alarm Light 12-8970-10



Provides a bright visual for precise loading and unloading

*Not Available for use with EZ 2500

Helm Welding Limited Call for flyer: 519-529-7627 Tel: 519-529-7000 www.lucknowproducts.com Fax: 519-529-3260 www.digi-star.com ©2017 Digi-Star

We reserve the right to modify designs or implement product improvement, without any obligations with respect to goods purchased.



